

Description		Part No.	Kits Req.	Kit Qty	Notes
	Sway Bar - Link Bushes	42364	1	4	OD=21, ID= 8, L=13mm
	Sway Bar - Link Bushes	42080	1	8	OD=21, ID= 8, L=13mm
	Sway Bar - Link Bushes	43010	1	4	OD=28.5, ID=10, L=15mm
	Sway Bar - Link Bushes	42915	1	8	OD=28.5, ID=10, L=15mm
	Sway Bar - Link Bushes	42002	1	8	OD=28.5, ID=10, L=18.5mm
	Sway Bar - Link Bushes	43019	1	8	OD=29.5, ID=10, L=14.5mm
	Sway Bar - Mounting Bracket	42934	1	2	X = 50mm - Suits Mount Bushes Below
	Sway Bar - Mounting Bracket	42931	1	2	X = 65mm - Suits Mount Bushes Below
	Sway Bar - Mounting Bracket	42935	1	2	X = 95mm - Suits Mount Bushes Below
	Sway Bar - Mounting Bracket	42936	1	2	X = 110mm - Suits Mount Bushes Below
	Sway Bar - Mount 14mm	42914	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 16mm	42916	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 17mm	42917	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 18mm	42918	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 19mm	42919	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 20mm	42920	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 21mm	42921	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 22mm	42922	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 23mm	42923	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 24mm	42924	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 25mm	42925	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 26mm	42926	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 27mm	42927	1	2	Suits Mounting Brackets Above
	Sway Bar - Mount 28mm	42928	1	2	Suits Mounting Brackets Above
Sway Bar - Mount 30mm	42930	1	2	Suits Mounting Brackets Above	

BULK BUSHES - 11 FAST MOVING PART NUMBERS

This range consists of popular 4WD & light commercial spring eye & shackle bushes as well as our most popular sway bar link and panhard rod bushes.
 N.B: Nolathane Budget Busters have a different part number system. By replacing the prefix 4 with KU and adding /100 as a suffix to denote packs of 100 bushers. The rest of the part No. remains the same.

Part #	Series	Model	Loc	Description	Qty Req	Notes
KU2915/100	Suits 100's of listings refer application section for direct vehicle fitment details					
KU7001/100	Dyna	LH80,YH81,YY100	R	Spring - eye front/rear & shackle	12	Refer Hi-Lux pg 130-133
	Hi-Ace	LH30/RH11,20,32,42	R	Spring - eye front/rear & shackle	12	
	Hi-Lux	Most Models	R	Spring - eye rear & shackle	12	
	Hi-Lux/4 Runner	LN60,YN60	F	Spring - eye front/rear & shackle	8	
	Hi-Lux/4 Runner	LN/YN60 Series	R	Spring - eye front/rear & shackle	12	
	Landcruiser	40 Series	R	Spring - eye front/rear & shackle	12	
	Lite Ace	CM/KM/YM Series	R	Spring - eye front/rear & shackle	12	
KU7003/100	Commodore	VY 1 Tonner/Crewman	R	Spring - eye rear & shackle	8	
	Jackaroo	UBS13,16,17,52,56	R	Spring - eye rear & shackle	8	
	Rodeo	KB Series	R	Spring - eye front/rear & shackle	12	
	Rodeo	TF Series	R	Spring - eye rear & shackle	8	
KU7004/100	Landcruiser	40 Series	F/R	Spring - eye front/rear & shackle	12	
	Stout	RK101,110	F	Spring - eye front/rear & shackle	12	
KU7005/100	Patrol/Maverick	GQ Y60/DA	R	Spring - eye front/rear & shackle	12	Refer Landcruiser pg 134-139
	Landcruiser	Most Models	F/R	Spring - eye front/rear & shackle	12	
KU7008/100	Dyna	LY60	F/R	Spring - eye front/rear & shackle	12	
	Landcruiser	40 Series	R	Spring - eye front/rear & shackle	12	
	Landcruiser	FJ55	F/R	Spring - eye front/rear & shackle	12	
	Stout	RK101,110	R	Spring - eye front/rear & shackle	12	
	Toyo Ace	RY16;LY30,31,RY31	F/R	Spring - eye front/rear & shackle	12	
KU7018/100	Landcruiser	70 Series	R	Spring - eye front/rear & shackle	12	
KU7019/100	Navara	D21,D22	R	Spring - eye rear & shackle	8	
KU7021/100*	Landrover	Series 2A,3	F/R	Spring - eye front & rear	8	
KU7022/100	Hi-Lux	Most Models	F	Spring - eye rear & shackle	4	Refer Hi-Lux pg 130 - 133
KU8002/100*	Commodore	VB - VS	R	Panhard rod	2	1 piece design refer 48002 (2 piece)
	Gemini	TX - TG (excl p/van)	R	Panhard rod	2	1 piece design refer 48002 (2 piece)

* denotes crusetube included in kit