

Instructions

Rear Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application - Chev Cobalt
- 2006-2008

Always refer complete catalogue listing

- Raise vehicle evenly and safely support.

Never rely on a Jack only

- Place supplied stepped washer inside suspension Beam - refer RH image below.

- Proceed to bolt up swaybar bracket with supplied M12 bolt/nut and 1 washer - do not tighten yet.

- Bolt up swaybar as per lower image - use supplied M12 bolts/nuts. Place supplied washers against swaybar blade and bracket.

- Tighten all bolts to 80Nm

- Re-check all bolts after 100-500Kms travelled.

Tip - use tape to hold stepped washer during install!

Contents - 1x 26mm swaybar
- 6x M12 bolts
- 6x M12 nuts
- 10x flat washers
- 2x swaybar brackets
- 2x stepped washers

Place stepped washer inside Beam



Don't tighten bolts until all 6 are started.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.