

Nolathane Part No's. 42700 & 42701 Subaru Polished Alloy Sway Bar Links

REPLACES O.E. GLASS FIBRE COMPOSITE LINKS

This 42700 **Nolathane** kit suits FRONT:

Forester SF MY97-02
Impreza GC Sedan (Incl. WRX) MY94-00
Impreza GF-GH Wagon (Incl. WRX) MY94-03
Liberty (Legacy) BC/BD Sedan 1989-99
Liberty (Legacy) BF/BG/BH Wagon 1989 on
Outback MY99-00

This 42701 **Nolathane** kit suits REAR:

Forester SF MY97-02
Impreza GC/GD Sedan (Incl. WRX) MY94-03
Impreza GF-GH Wagon (Incl. WRX) MY94-03
Liberty (Legacy) BC/BD Sedan 1989-99 (Excl Series 1)
Liberty (Legacy) BF/BG/BH Wagon 1989 on
Outback MY99-03



O.E. links & O.E. bushes - check for cracks here.



O.E. links & **Nolathane** bushes.

The original sway bar links on these Subaru models, including WRX, are made from a glass composite plastic. As the vehicle turns into a corner, initial body roll occurs and the original soft rubber bushes compress at the same time the original links flex. This compression of the rubber bushes and flexing of the links means that the sway bar is not initially working as the load is cushioned by the bushes & links and not controlled by the sway bar. It is also common to find small fractures in the original links, particularly the rear links which become stressed around the "C" shaped bend in the link.

The **Nolathane** links are made from high strength polished alloy to ensure there is virtually no flex. They are fitted with **Nolathane** bushes which do not compress as much under load. The combination of the alloy links and **Nolathane** bushes provides an almost immediate sway bar response. This responsiveness can really be felt during initial turn-in and lane changing etc. The **Nolathane** design permits full articulation of the suspension on standard height or lowered vehicles. Each kit includes either front OR rear alloy links, **Nolathane** bushes, nuts, bolts, washers & crusstubes.

Replacement **Nolathane** bushes are available for both the original glass composite links and these alloy links.

The part number for the bushes for the O.E. links are:

42411 suits O.E. front links
42412 suits O.E. rear links



Shows Nolathane front ("I" shape) & rear ("C" shape) links

NOLATHANE

2/4 Warringah Close
Somersby NSW 2250
Ph (02) 4340 2355
Fax (02) 4340 2466

ABN 78 003 734 183

TECHNICAL HOTLINE

Phone: Australia 1300 88 2355
Email: tech@redranger.com.au

Fax: Australia (02) 4340 2466

TECHNICAL CALL BACK SERVICE

New Zealand +61 2 4340 2355
New Zealand +61 2 4340 2466
For fitment, applications, sizes and cross reference information.