

Fitting Instructions

For Front strut mount bush

To suit: Daihatsu Charade G100, G102 6/87-7/93

Contents:

Replacment bush x 4 Grease satchel x 1 Instruction sheet x 1

These instructions are to be used in conjunction with workshop manual.

1. Raise the front of the vehicle and support on chassis stands, remove the front wheels.
 2. Remove the brake hose mounting bracket clip and hose from bracket
 3. Remove the two lower strut mount bolts and separate bottom of strut from hub
 4. Remove the two upper strut mount nuts and remove the front strut assembly from the vehicle
- Note: COMPRESSED SPRINGS ARE DANGEROUS - PLEASE USE CAUTION.
5. Compress the coil spring with suitable spring compressors and remove the strut rod retaining nut
 6. Mount the strut top in a vice and drill out the spot welds with a 5mm drill bit.(as per diagram A)

Diagram A



7. Separate the upper part of the strut top from the bottom washer by holding the drilled strut mount in the vice and using a chisel to gently separate the two sections (as per diagram B)

Diagram B



8. Remove the existing rubber bush from the top part of the mount. Remove any paint, rust, burrs or sharp edges from the face of the mount and install the replacement bush 4020 using liberal amounts of grease supplied on contact surfaces (as per diagram C)
9. Re fit the strut mount assembly and coil spring to the strut and refit assembly to the vehicle

Diagram C



10. We recommend a wheel alignment be carried out at this time.

NB: It is recommended that a licensed workshop or trades person carry out the above procedure and that workshop manual procedures are followed in addition to the above.