

CASTER KITS

Please Note: URETHANE BUSHES MUST BE FITTED TO BOTH SIDES

45232 – STANDARD REPLACEMENT/ALIGNMENT

Original equipment style bushes, which maintain existing caster settings.

<u>Kit contents:</u>	9025 - Left/Right Hand Side	x 2
	Crush tubes	x 2
	Steel Washers	x 2

45368 – 0.6 DEGREE CASTER OFFSET LEFT SIDE

LH Offset gives +0.6 Degree caster

RH Std maintains caster settings

<u>Kit contents:</u>	9025 - Right Hand Side	x 1
	9024 – Left Hand Side	x 1
	Crush tubes	x 2
	Steel Washers	x 2

N.B: The Std bush **9044** is slightly offset as per the original bushes, please ensure correct installation in accordance to original specifications.

45369 – 0.6 DEGREE CASTER OFFSET BOTH LH & RH SIDES

LH Offset gives +0.6 Degree caster

RH Offset gives –0.6 Degree caster

<u>Kit contents:</u>	9024 – Left/Right Hand Side	x 2
	Crush tubes	x 2
	Steel Washers	x 2

SPECIAL NOTE: “STEEL WASHERS” included in this kit must be used to prevent movement when braking. Ensure that the washer is fitted to the front of the bush to prevent the bush walking up over the stop on the arm & also damaging the bushes face.

NB: Pivot shafts and mounting brackets must be free from dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with grease provided.

All mounting bolts are to be torque to MANUFACTURES SPECIFICATIONS with the vehicle at normal ride height.