

LANTRA / LANCER CASTER KITS

Please Note: URETHANE BUSHES MUST BE FITTED TO BOTH SIDES

45362 – STANDARD REPLACEMENT/ALIGNMENT

Kit contents: 1 x 9017 Left Hand Side
1 x 9018 Right Hand Side

Original equipment style bushes, which maintain existing caster settings.

45363 – 0.6 DEGREE CASTER ADJUSTMENT LEFT SIDE

Kit contents: 1 x 9019 Left Hand Side (Offset gives 0.6 Degree caster)
1 x 9018 Right Hand Side (Maintains existing caster settings)

45364 – 0.6 DEGREE CASTER ADJUSTMENT BOTH SIDES

Kit contents: 1 x 9019 Left Hand Side (Offset gives +0.6 Degree caster)
1 x 9020 Right Hand Side (Offset gives -0.6 Degree caster)

NB: Pivot shafts and mounting brackets must be free from dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with grease provided.

Fitting the correct bush to the car, the word “**FRONT**” moulded into the bush must be facing forwards (the word “**FRONT**” is clearly visible once fitted).

All mounting bolts are to be torque to MANUFACTURES SPECIFICATIONS with the vehicle at normal ride height.