

Trailing Arm Bushing

Application:
Jeep Grand Cherokee
(1999-2006)

Contents:
2x bushings
2x tubes
1x grease

Note: Do not remove original OE shell from trailing arm.



1. Raise vehicle evenly - safely support.
2. Un-bolt and remove lower trailing arms.
3. Proceed to remove the internal rubber.
with in the rear bushing - DO NOT remove the bushings outer shell.
4. Using soapy water, press the supplied bushing into the original steel shell.
5. Grease bushing ID and faces and push tube into position. Re-fit arms to vehicle.
6. Re-check all bolts after initial 100km's travelled.