

Instructions - Rack Bushings

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application - Toyota Tundra
2WD & 4WD

Install Guide

1. Raise vehicle evenly and safely support.

Note - its possible to remove OE bushings with rack hanging in vehicle.

Lock the steering wheel in the centre position.

2. Proceed to remove the front wheels and any plastic under-covers.

3. Un-bolt rack from Sub-frame. Also disconnect ball joints. Pull the rack gently to gain better access to bushings.

4. The OE bushings do not have a steel outer shell - so they can be pulled out with a nut and bolt and large socket. Silicon spray will help.

5. Once OE bushings removed, push in supplied bushings. Note each bushing position as per below. Re-use OE hardware.

6. Re-fit Rack - tighten bolts to OE specification. Carry out a wheel alignment.

Contents - 1x bushing 1096
2x bushings 90476
2x bushings 90700
1x steel tube 41mm
1x steel tube 74.4mm
1x washer

Bushing 1096 sits under OE steel bracket.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.