

Instructions

Body Mount Bushings

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 1 of 2

Application - Chev C10 1973-80

(Refer current catalogue for complete listing)

Note: Any rusted nuts or bolts will require lubricant prior to disassemble.

When removing each mount, be sure to note each location on vehicle. Also, any existing shims will need to be re-used in their respective point

Contents - 6x steel washers 49mm OD
 - 2x steel washers 63mm OD
 - 4x steel washers 76mm OD
 - 4x bushings 90287
 - 4x bushings 90288
 - 2x bushings 90309
 - 2x bushings 91331
 - 4x steel tubes 58mm L
 - 2x steel tubes 35mm L

1. Loosen all bolts on both sides of vehicle initially.

**Be careful of fan shroud and other components while lifting.
 A hydraulic jack and timber may be used to lift the body.**

2. Proceed by replacing mounts from 1 side of vehicle at a time.

3. Replace 1 mount at a time, but do not tighten bolts yet - note diagram on page 2 for bushing position.

4. Once all mounts are replaced, confirm body is straight/aligned - tighten all nuts to Manufacturers specifications.

5. It is recommended all hardware is re-checked after 500kms travelled.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Body Mount Bushings

