

RADIUS ARM – CHASSIS MOUNT LANDROVER, DISCOVERY, RANGE ROVER

1. Support vehicle and rear differential. Remove rear radius arm by unbolting at differential and removing lock nuts at chassis softmounts.
2. Remove 3 bolts on each side of chassis and replace rubber mounts with replacements

NOTE: Centre crush tubes in mounts have 16mm and 20mm internal diameter. Ensure the shank at the end of the radius rod has the correct diameter to suit mount. A 16mm radius rod in a 20mm ID mount could lead to premature failure of the mount.

3. Reassemble suspension as recommended in the workshop manual.

This procedure must be carried out by a qualified person