

TN-TP MAGNA & SONATA CASTER KITS

Please Note: URETHANE BUSHES MUST BE FITTED TO BOTH SIDES

45239 – STANDARD REPLACEMENT/ALIGNMENT

Kit contents: 2 x 9049 Left/Right Hand Side

Original equipment style bushes, which maintain existing caster settings.

45407 – 0.8 DEGREE CASTER ADJUSTMENT LEFT SIDE

Kit contents: 1 x 9051 Left Hand Side (Offset gives +0.8 Degree caster)
1 x 9049 Right Hand Side (Maintains existing caster settings)

45409 – 0.8 DEGREE CASTER ADJUSTMENT BOTH SIDES

Kit contents: 1 x 9051 Left Hand Side (Offset gives +0.8 Degree caster)
1 x 9051 Right Hand Side (Offset gives -0.8 Degree caster)

NB: Pivot shafts and mounting brackets must be free from dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with grease provided.

Fitting the correct bush to the car, the word “**FRONT**” moulded into the bush must be facing downwards and forwards (the word “**FRONT**” is clearly visible once fitted).

All mounting bolts are to be torque to MANUFACTURES SPECIFICATIONS with the vehicle at normal ride height.